



R311 / R313 Series

Satisfy All Your Needs for Indoor Applications

Smart Home



【R311A / R313A】 Wireless Door / Window Sensor

- ◆ Monitor the opening and closing of doors, windows, and drawers.
- ◆ Sound alarms and connect with other devices such as light switches.



【R311B】 Wireless Light Sensor

- ◆ Detect outdoor light level.
- ◆ Connect with other devices to modulate indoor lighting.



【R312 / R313M】 Wireless Doorbell Button

- ◆ Detect the status of a doorbell and if it's triggered.
- ◆ Connected with sirens and light switches.

Smart Hotel



【R311CA / R313CA】 Wireless Dry Contact Sensor

- ◆ Connected with emergency button, curtain switch, door magnet, infrared detection, and electric key card switch.



【R311G / R313G】 Wireless Light Sensor

- ◆ Built-in light sensor to detect ambient light intensity, report illuminance value, and connect other devices to modulate illuminance intensity.



【R312 / R313M】 Wireless Emergency Button

- ◆ Installed in rooms and restrooms for emergent situations.



【R311LA / R313LA】 Wireless Infrared Proximity Sensor

- ◆ Detect the presence of toilet paper and sound alarms.

Medical Institutions



【R312A/R313MA】 Wireless Emergency Button

- ◆ Installed in rooms, restrooms, and any place that patients and elders might need help.

【R311WA / R313WA】 Wireless Seat Sensor

- ◆ Installed in beds to detect if patients are falling.
- ◆ Installed under chairs to monitor if the elders sit for too long.




Security System for Shops



【R311CB / R313CB】 Wireless Window / Door Sensor with Glass Break Detector

- ◆ Installed on doors and windows to detect the opening, closing, and damage of glasses.



【R311D / R313D】 Wireless Asset Sensor

- ◆ Installed on moving objects and provide a simple positioning function.



【R311DA / R313DA】 Wireless Vibration Sensor (Ball-Type)

- ◆ Installed on doors and windows to detect if any damage happened.

R311 / R313 Series

| Model | Name |
|---------------|---|
| R311A/R313A | Wireless Door/Window Sensor |
| R311B/R313B | Wireless Light Sensor |
| R311CA/R313CA | Wireless Dry Contact Sensors |
| R311CB/R313CB | Wireless Window/Door Sensor and Wireless Glass Sensor |
| R311CC/R313CC | Wireless 2-Gang Reed Switch Open/Close Detection Sensor |
| R311D/R313D | Wireless Asset Sensor |
| R311DA/R313DA | Wireless Vibration sensor(ball type) |
| R311DB/R313DB | Wireless Vibration sensor(Spring Type) |
| R311FA/R313FA | Wireless Activity Detection Sensor |
| R311FB/R313FB | Wireless Activity Event Counter |
| R311FC/R313FC | Wireless Activity Timer |
| R311FD | Three-Axis Digital Accelerometer |
| R311G/R313G | Wireless Light Sensor |
| R311K/R313K | Tilt detection Sensor |
| R311LA/R313LA | Wireless toilet paper detection sensor |
| R311W/R313W | Wireless Water Leak Detector |
| R311WA/R313WA | Wireless Seat Occupy Sensor |
| R312/R313M | Wireless Door Bell Button |
| R312A/R313MA | Wireless Emergency button |

R311 series VS. R313 series



Built-in sensor
Simple design



External sensor
Stable performance