

netvox

Wireless 2-Gang Door/Window Sensor

R311CC User Manual

Copyright©Netvox Technology Co., Ltd.

This document contains proprietary technical information which is the property of NETVOX Technology. It shall be maintained in strict confidence and shall not be disclosed to other parties, in whole or in part, without written permission of NETVOX Technology. The specifications are subject to change without prior notice.

Table of Content

1. Introduction	. 2
2. Appearance	. 3
3. Main Features	
4. Set up Instruction	. 4
5. Data Report	
6. Installation	
7. Important Maintenance Instruction	10

1. Introduction

R311CC is equipped with two external reed switches, which can be used for door and window switch state detection.


LoRa Wireless Technology:

LoRa is a wireless communication technology famous for its long-distance transmission and low power consumption. Compared with other communication methods, LoRa spread spectrum modulation technique greatly extend the communication distance. It can be widely used in any use case that requires long-distance and low-data wireless communications. For example, automatic meter reading, building automation equipment, wireless security systems, industrial monitoring. It has features like small size, low power consumption, long transmission distance, strong anti-interference ability and so on.

LoRaWAN:

LoRaWAN uses LoRa technology to define end-to-end standard specifications to ensure interoperability between devices and gateways from different manufacturers.

2. Appearance



3. Main Features

- Compatible with LoRaWAN
- 2 sections of 3V CR2450 button batteries
- 2-gang Reed switch status detection
- \bullet Compatible with LoRaWAN^{TM} Class A
- Frequency hopping spread spectrum
- Configuration parameters can be configured via a third-party software platform, data can be read and alerts can be set via SMS text and email (optional)
- Applicable to third-party platforms: Actility/ThingPark, TTN, MyDevices/Cayenne
- Low power consumption and long battery life

4. Set up Instruction

On/Off

	Insert batteries. (users may need a flat blade screwdriver to open);				
Power on	Insert two sections of 3V CR2450 button batteries and close the battery				
	cover.)				
Turn on	Press any function key till green and red indicator flashes once.				
Turn off	Press and hold the function key for 5 seconds till green indicator flashes for 20				
(Restore to factory setting)	times.				
Power off	Remove Batteries.				
	1. Remove and insert the battery; the device memorizes previous on/off				
	state by default.				
Note:	2. On/off interval is suggested to be about 10 seconds to avoid the interference				
Note.	of capacitor inductance and other energy storage components.				
	3. Press any function key and insert batteries at the same time; it will enter				
	engineer testing mode.				

Network Joining

	Turn on the device to search the network.				
Never joined the network	The green indicator stays on for 5 seconds: success				
	The green indicator remains off: fail				
	Turn on the device to search the previous network.				
Had joined the network	The green indicator stays on for 5 seconds: success				
	The green indicator remains off: fail				

Function Key

	Restore to factory setting / Turn off				
Press and hold for 5 seconds	The green indicator flashes for 20 times: success				
	The green indicator remains off: fail				
D	The device is in the network: green indicator flashes once and sends a report				
Press once	The device is not in the network: green indicator remains off				

Sleeping Mode

The device is on and in the network	Sleeping period: Min Interval.
	When the reportchange exceeds setting value or the state changes: send a data
	report according to Min Interval.
Low Voltage Warning	

Low Voltage Warning

Low Voltage	2.4V	
-------------	------	--

5. Data Report

The device will immediately send a version packet report along with an uplink packet including reed

switch status and battery voltage.

Data will be reported by default setting before any configuration.

Default setting:

Maximum time: 3600s

Minimum time: 3600s (Detect the current voltage value every 3600s by default setting)

Battery Change :0x01 (0.1V)

R311CC status:

When the R311CC status changes, it will send a warning report.

Window/Door sensor open : 1

Window/Door sensor close : 0

The reported data is decoded by the Netvox LoRaWAN Application Command document and

http://www.netvox.com.cn:8888/cmddoc

Data report configuration and sending period are as following:

Min Interval	Max Interval	Reportable Change	Current Change≥	Current Change <
(Unit:second)	(Unit:second)		Reportable Change	Reportable Change
Any number	Any number	Can not be 0.	Report	Report
between 1~65535	between 1~65535		per Min Interval	per Max Interval

Example of ConfigureCmd

FPort: 0x07

Bytes	1	1	Var (Fix =9 Bytes)
	CmdID	DeviceType	NetvoxPayLoadData

CmdID-1 byte

DeviceType– 1 byte – Device Type of Device

NetvoxPayLoadData- var bytes (Max=9bytes)

Decomintion	Davias	Cmd	Device	NetvoxPayLoadData				
Description	Device	ID	Туре					
Config				MinTime	MaxTime		Battery	Reserved
Config		0x01		(2bytes	(2bytes		Change	(4Bytes,Fixed
ReportReq				Unit:s)	Unit:s)	(1by	te Unit:0.1v)	0x00)
Config		0x81		Status			Reserved	
ReportRsp	R311CC	0x81	0x6C	(0x0	00_success)	(8Bytes,		Fixed 0x00)
ReadConfig	KJIICC	0x02	UXOC	Reserved (9Bytes,Fixed 0x00)				
ReportReq		0X02						
DeadConfig				MinTime	MaxTime		Battery	Reserved
ReadConfig		0x82		(2bytes	(2bytes		Change	(4Bytes,Fixed
ReportRsp				Unit:s)	Unit:s)	(1by	te Unit:0.1v)	0x00)

(1) Command Configuration:

MinTime = $1 \min_{n}$ MaxTime = $1 \min_{n}$ BatteryChange = 0.1v

Downlink: 016C003C003C010000000 $003C(H_{ex}) = 60(D_{ec})$

Response:

816C000000000000000000 (Configuration success)

816C010000000000000000000 (Configuration failure)


(2) Read Configuration:

Downlink:	026C00000000000000000
Response:	826C003C003C0100000000 (Current configuration)

Example for MinTime/MaxTime logic

Example#1 based on MinTime = 1 Hour, MaxTime= 1 Hour, Reportable Change

i.e.BatteryVoltageChange=0.1V




Note:

MaxTime=MinTime. Data will only be report according to MaxTime (MinTime) duration

regardless BtteryVoltageChange value.


Example#2 based on MinTime = 15 Minutes, MaxTime= 1 Hour, Reportable Change



i.e. BatteryVoltageChange= 0.1V.

Example#3 based on MinTime = 15 Minutes, MaxTime= 1 Hour, Reportable Change

i.e. BatteryVoltageChange= 0.1V.




Notes:

- The device only wakes up and performs data sampling according to MinTime Interval.
 When it is sleeping, it does not collect data.
- (2) The data collected is compared with the last data <u>reported</u>. If the data change value is greater than the ReportableChange value, the device reports according to MinTime interval. If the data variation is not greater than the last data reported, the device reports according to MaxTime interval.
- (3) We do not recommend to set the MinTime Interval value too low. If the MinTime Interval is too low, the device wakes up frequently and the battery will be drained soon.
- (4) Whenever the device sends a report, no matter resulting from data variation, button pushed or MaxTime interval, another cycle of MinTime/MaxTime calculation is started.

6. Installation

- (1) This product does not have a waterproof function. After the screening is completed, please place it indoors.
- (2) Dust in the installation position of the equipment needs to be wiped clean and then affixed to the equipment.
- (3) The battery installation method is shown in the figure below (battery with "+" facing outward).



Note: To install the battery, use a screwdriver or similar tool to assist in opening the battery cover.

7. Important Maintenance Instruction

Kindly pay attention to the following in order to achieve the best maintenance of the product:

- Keep the device dry. Rain, moisture, or any liquid, might contain minerals and thus corrode electronic circuits. If the device gets wet, please dry it completely.
- Do not use or store the device in dusty or dirty environment. It might damage its detachable parts and electronic components.
- Do not store the device under excessive heat condition. High temperature can shorten the life of electronic devices, destroy batteries, and deform or melt some plastic parts.
- Do not store the device in places that are too cold. Otherwise, when the temperature rises to normal temperature, moisture will form inside, which will destroy the board.
- Do not throw, knock or shake the device. Rough handling of equipment can destroy internal circuit boards and delicate structures.
- Do not clean the device with strong chemicals, detergents or strong detergents.
- Do not apply the device with paint. Smudges might block in the device and affect the operation.
- Do not throw the battery into the fire, or the battery will explode. Damaged batteries may also explode.

All of the above applies to your device, battery and accessories. If any device is not working properly, please take it to the nearest authorized service facility for repair.